


Tips for use CUBE



General

With the Quooker CUBE, you can dispense filtered chilled and sparkling water straight from your Quooker tap. Read the tips below to optimise your use of the CUBE. Also read the 'Tips for use' which you received with your Quooker tank for information about its use.




fig. 1

Tap operation

With a Quooker CUBE connected to your Quooker tank, you can easily switch between boiling, hot, cold, filtered chilled and sparkling water. Hot and cold water are dispensed by using the mixer handle. Boiling, filtered chilled and sparkling water are dispensed using the textured ring.

Boiling water (fig. 1)

Boiling water is dispensed by first pushing the textured ring down twice, then turning it anti-clockwise. The LED ring will light up red and stay red while boiling water is dispensed. In addition to this safety feature, the pull-out flexible hose on the Flex tap will immediately cut off the boiling water, if it is pulled out of the spout.




fig. 2

Filtered chilled water (fig. 2)

Press the textured ring down once and hold it down until the LED turns solid blue, then turn it anti-clockwise. Filtered chilled water will now be dispensed.




fig. 3

Filtered sparkling water (fig. 3)

To dispense sparkling water, press the textured ring down once, then turn it anti-clockwise immediately. The tap LED will now flash blue and keep flashing whilst sparkling water is dispensed. Turn the ring back to close the tap. A small amount of water will continue to flow to ensure all sparkling water is flushed out of the tap spout.




fig. 4

First use (fig. 4)

Once the CUBE has been connected, flush the CUBE's filtered & sparkling water through twice for one minute each time (the tap switches off automatically after one minute). This will flush away any impurities there might be in the pipes. The sparkling water tank in the CUBE cools down within 60 minutes after installation. The exact length of time depends on the temperature of the inflowing water.



fig. 5

Changing the CO₂ cylinder (fig. 5)

The supplied CO₂ cylinder is filled with carbon dioxide that provides approximately 60 litres of sparkling water. When the flow of sparkling water becomes reduced and there are less bubbles in the water, the CO₂ cylinder should be replaced. When the CO₂ cylinder is completely empty, no water will come out when you try to dispense sparkling water. You can then order a new set of four CO₂ cylinders via quooker.co.uk. Clear instructions for how to replace a CO₂ cylinder are printed on the cylinder itself. Empty CO₂ cylinders must be returned to Quooker. This is free of charge. The CO₂ cylinders are issued on loan and remain property of Quooker. If the empty cylinders are not returned to Quooker within 60 days of receipt of the new ones, Quooker is entitled to recover the cost of these cylinders from the user. For quality and safety reasons, the CO₂ cylinders can only be refilled by Quooker. Only genuine Quooker parts should be used with a Quooker and use of any third party parts of any sort will void the warranty.



fig. 6

Replace filters (fig. 6)

The CUBE is equipped with an active carbon filter and a hollow fibre filter. Both filters together ensure a better water quality because they filter bacteria, chloride, chemicals and pesticides from the water. For hygienic reasons, the filters should be replaced every 12 months, regardless of the amount of water used. After 12 months, the CUBE will start beeping and the light on the CUBE tank will flash to indicate that the filters need to be replaced (fig. 7). The filters can be accessed under the sliding panel on top of the CUBE. Instructions for replacing the filters are printed on the filter cartridges.




fig. 7

The beeping sound can be snoozed for 72 hours, giving you time to order new filters via quooker.co.uk. To do this, briefly press the red illuminated button under the sliding panel on top of the CUBE.

Once the filters have been replaced, you can reset the timer for another 12 months. To do this, press & hold the red illuminated button under the sliding panel for 5 seconds. The CUBE will then beep and the red light will go out.

Maintenance

Clean the CUBE's ventilator fan once a year using a brush or vacuum cleaner.

In addition, the CUBE's filters should be replaced annually. The CUBE will flash and beep to indicate when this should be done. Clear instructions for replacing the filters are printed on the filter cartridges. Replacement filters can be ordered via quooker.co.uk

Going on holiday? Turn off the CUBE and flush it through when you return.

If you're going away for more than 2 weeks, we advise turning the CUBE off using the switch at the back of the CUBE or by turning off the power at the power socket. When returning home, it's important to flush the CUBE through by dispensing both chilled and sparkling water twice for one minute each time (the tap switches off automatically after one minute).

Malfunction

If the CUBE stops working correctly, please contact our service department on 0207 9233355 or by e-mail: service@quooker.co.uk

Answers to frequently asked questions can be found on our website under Service: quooker.co.uk

Warranty and service

The warranty period for the CUBE and Quooker system is two years and covers supply of parts only. It does not cover labour costs or any mechanical failure due to limescale. Only genuine Quooker parts should be used with a Quooker and use of any third party parts of any sort will void the warranty. Register your Quooker at quooker.co.uk/enuk/register-your-quooker.

Quooker®

Quooker UK Ltd.
Beaumont Buildings
Great Ducie Street
Manchester M3 1PQ (UK)
0207 9233355
info@quooker.co.uk
quooker.co.uk